Service.



Workshop Manual

Avant RS2 1994 ►

Edition 03.1994



Assembly and Repair Group Index to Workshop Manual

Avant RS2 1994 ▶

Edition 03.94

All the assemblies of the RS2 are listed in the repair group index.

The current flow diagrams and repair procedures of the relevant assemblies and repair groups which differ are all described in this manual \Rightarrow Contents.

Where the repair procedures are identical reference is made to the relevant assembly of the Audi 80 1992 ► and Audi 100 1991 ► respectively.

This binder is issued as a loose leaf system.

Updating

Revisions and additions appear as supplements; in this case, the relevant pages should then be replaced.

Assembly	⇒ Workshop Manual		
Electrical System	Audi 80 1992 ► Electrical System		
Heating, Air Conditioning	Audi 80 1992 ► Heating, Air Conditioning		
General Body Work	Audi 80 1992 ► General Body Work		
Body Repairs	Body Repairs		
6-speed Manual Transmission 01E 4WD	Audi 100 1991 ► 5- and 6-speed Manual		
	Transmission 01E 4WD		
Assembly			
Current Flow Diagrams Avant RS2	⇒ Contents		
Running Gear 4WD	Audi 80 1992 Running Gear 4WD		
Repair Group	Repair Group ►		
01 Self-diagnosis	01 Self-diagnosis		
48 Steering	48 Steering		
All Other Repair Groups	⇒ Contents		
5-Cyl. Engine (4-valve Turbo) Mechanics	⇒ Contents		
Motronic			
Injection and Ignition System (5-Cylinder)	⇒ Contents		
Repair Group	Repair Group		
	01 Self-diagnosis		
	24 Mixture Preparation, Injection		
28 Ignition System	⇒ Workshop Manual		
	Audi 80 1992 ► Motronic		
	Injection and Ignition System (5-Cylinder)		
	28 Ignition System		

Technical information should always be available to all foremen and mechanics because compliance with the instructions given is essential to ensure vehicle road worthiness and safety. In addition, the normal safety precautions to be observed when working on motor vehicles are also applicable.

Supplement Index to Workshop Manual

Avant RS2 1994 ►

- Please enter the date of issue of the Supplement. This enables you to see whether all the Supplements have been filed and that the Workshop Manual is thus up-to-date.

Supplement	Edition	Article Number
1		000.5463.31.20
2		000.5463.32.20
3		000.5463.33.20
4		000.5463.34.20
5		000.5463.35.20
6		000.5463.36.20
7		000.5463.37.20
8		000.5463.38.20
9		000.5463.39.20
10		000.5463.40.20
11		000.5463.41.20
12		000.5463.42.20
13		000.5463.43.20
14		000.5463.44.20
15		000.5463.45.20
16		000.5463.46.20
17		000.5463.47.20
18		000.5463.48.20
19		000.5463.49.20
20		000.5463.50.20

Contents next page

Contents

	Current Flow Diagrams Avant RS2	Page
	Relay position assignment	1
	- Immobilizer	2
	Motronic control unit, trailer recognition	
	- Motronic control unit, heated rear window	
	- Turn signal and hazard warning flasher system, licence plate light	
	Bulb monitoring device, trailer coupling	
	- Trailer coupling, rear fog lamp	
	Electrically adjustable driver and front passenger mirror	
	 All other non-Avant RS2 specific current flow diagrams ⇒ Workshop Manual Audi 80 Current Flow Diagrams, Electrical Fault Finding and Fitting Locations binder 1992 ► 	
00	Technical Data	Page
	Technical data	00- 1
	- Engine number	00- 1
	- Engine features	00- 2
01	Self-diagnosis	Page
	Motronic self-diagnosis	
	- Fault table	
	- Basic setting of engine with V.A.G 1551	
	- Coding variants of Motronic control unit –J220	
	- For repair procedures below ⇒ Audi 80 1992 ► Motronic Fuel Injection and Ignition System (5-C	ylinder)
	- Interrogating and erasing fault memory with fault reader V.A.G 1551	
	- Final control diagnosis with fault reader V.A.G 1551	
	Testing cable connection of diagnostic sockets	
	- Removing and installing Motronic control unit	
	- Connecting test box V.A.G 1598	
	- Reading measured value block	
	 Interrogating control unit version with V.A.G 1551 	
10	Removing and Installing Engine	Page
	Removing and installing engine	10- 1
13	Crankshaft Group	Page
	Crankshaft group	13- 1
15	Cylinder Head, Valve Gear	Page
	Cylinder head, Valve gear	15- 1
17	Lubrication	Page
	Lubrication	_
19	Cooling System	Page
		19- 1
	Cooling system	13-

20	Fuel Supply System	Page
	Fuel supply system	20- 1
	Dismantling and assembling fuel pump	20- 1
	Testing delivery of fuel pump	20- 2
21	Charging	Page
	Charging	21- 1
	Removing and installing parts of charge air cooler	21- 2
	Testing exhaust gas turbocharger and blow-off valve	21- 3
24	Mixture Preparation, Injection	Page
	Motronic components	24- 1
	- Technical data	24- 1
	 For repair procedures below ⇒ Audi 80 1992 ➤ Motronic Fuel Injection and Ignition System (5-C) 	/linder)
	 Rules for cleanliness 	
	Safety precautions Repairing Motronic injection system	24- 2
	Testing system pressure and holding pressure	24- 2
	- Testing injectors	24- 2
	- Testing altitude sender -F96	24- 4
	Reduction in engine output when towing a trailer	24-10
	 For repair procedures below ⇒ Audi 80 1992 ▶ Motronic Fuel Injection and Ignition System (5-C) Testing fuel pump relay and actuation Testing idle speed and CO content Testing idle speed stabilization Testing Lambda probe and lambda control Removing and installing lambda probe Testing solenoid valve for activated charcoal filter Testing solenoid valve for boost pressure limiter Testing and adjusting idle speed switch Testing and adjusting throttle valve potentiometer Testing air mass meter Testing auxiliary signal of air conditioner and compressor cutoff Testing auxiliary signal of air conditioner for increasing engine speed Testing actuation of on-board computer for fuel consumption display Testing road speed signal Testing actuation of revolution counter Testing output signal for throttle valve position Testing auxiliary signal for reducing boost pressure when engine hot Pressure connections 	rlinder)
26	Exhaust System	Page
	Removing and installing exhaust system	26- 1
	Aligning exhaust system free of tension	26- 7 26-11
28	Ignition System	Page

For repair procedures below ⇒ Audi 80 1992 ► Motronic Fuel Injection and Ignition System (5-Cylinder)
 Motronic components


40	Front Suspension	Page
	Replacing wheel bearing housing	40- 1
	Removing and installing suspension strut and drive shaft	40- 6
	 For repair procedures below ⇒ Audi 80 1992 ➤ Running Gear 4WD 	70 0
	Servicing suspension strut	
	Servicing drive shaft	
	Servicing front suspension	
42	Rear Suspension	Page
	Replacing wheel bearing housing	42- 1
	Removing and installing drive shaft	42- 7
	 For repair procedures below ⇒ Audi 80 1992► Running Gear 4WD 	
	Servicing subframe	
	Servicing drive shaft	
	Servicing rear axle	
	Servicing suspension strut	
44	Wheels, Tyres, Wheel Alignment	Page
		_
	Fitting tyres	44– 1
	Wheels and tyres	44 5
	- Winter tyres	44- 5
	 For repair procedure below ⇒ Audi 80 1992 ► Running Gear 4WD 	
	Wheel alignment	
45	Anti-locking Brake System	Page
	Removing and installing ABS components on front axle	45- 1
	Removing and installing ABS components on rear axle	45- 5
	 For repair procedures below ⇒ Audi 80 1992 ► Running Gear 4WD 	
	Anti-locking brake system	
	Removing and installing hydraulic unit	
	Removing and installing components of electronic control	
46	Brakes, Brake Mechanics	Page
	Servicing front brakes	46 1
	- Inspecting brake pad thickness	46- 3
	- Replacing brake pads	46– 3
	- Installing	46– 6
	- Running in brake pads	46– 8
	Servicing rear brakes	46- 9
	Servicing handbrake	46-12
	Removing and installing handbrake cables	4616
	Adjusting handbrake	46-18
	 For repair procedure below ⇒ Audi 80 1992 ► Running Gear 4WD 	
	Removing and installing pedal group, servicing pedal group	
47	Brakes, Brake Hydraulics	Page
	Servicing four-piston fixed-caliper brake system	47- 1
	 For repair procedures below ⇒ Audi 80 1992 ► Running Gear 4WD 	,
	Removing and installing brake master cylinder/brake servo unit	
	Bleeding brake system and changing brake fluid	
	Location of brake pressure regulator	
	Lucation of plake pressure regulator	



Relay position assignment ⇒ Section "Fitting Locations"

Relay position with fuse holder:


Front auxiliary relay carrier (below dash panel on left)



Relay position assignment:

- Relay II for immobilizer

Relay I for immobilizer




Relay position assignment:

- Bulb monitoring device

Control unit for trailer recognition

Rear auxiliary relay carrier (below rear seat on left)



Relay position assignment:

Relay for switching off rear fog lamp (for towing trailer)

Colours of fuses

green


25 A - white 20 A - yello 15 A - blue 10 A - red 5 A - beige white

yellow

beige



Immobilizer



bl br brown = ge gn gr li yellow green = grey lilac = ro red black ws white

blue

В Starter

D Ignition starter switch

Н8 Horn for anti-theft warning system

Relay for starter inhibitor and reversing light J226

J341

J342 \$32

Relay I for immobilizer
Relay II for immobilizer
Relay II for immobilizer
Fuse for engine management I and ignition coil, electric cutoff valve (in auxiliary fuse holder)
Fuse for anti-theft warning system and immobilizer
Plug connection, 1-pin, black, below centre of rear seat

Plug connection, 2-pin, violet, below dash panel on left

Motor for central locking system with control unit for interior lamp time delay and anti-theft warning system

(83) Earth connection -1-, in front right wiring loom

Earth connection -1-, in central locking system wiring loom


Earth connection (control unit), in Motronic wiring loom

Connection (ignition coil-control unit), in front right wiring loom

Positive connection (30az), in window lifter/ central locking system and door contact switch wiring loom



Motronic control unit, trailer recognition



Ы blue br brown yellow ge gn gr li green grey lilac ro = red black SW ws white

F96 - Altitude sender

J155 - Control unit for coolant pump/exhaust gas turbocharger

J220 - Motronic control unit

J345 - Control unit for trailer recognition

S27 - Fuse for engine management I (in auxiliary fuse holder)

T2z - Plug connection, 2-pin, white, in plenum chamber close to relay plate (diagnostic connector)

Earth connection, engine earth, in front right wiring loom

(38) - Earth connection (control unit), in Motronic wiring loom

D3 - Connection (fuel gauge sender, 5V), in front right wiring loom

D9 - Positive connection (15) through fuse 24 in front right wiring loom

(E8) - Connection (screening), in Motronic wiring loom


K – Cable junction for diagnostic connector (K wire)

L - Cable junction for diagnostic connector (L wire)

Note: Cable junctions are bolted to the frame of the relay carrier (in plenum chamber).



Motronic control unit, heated rear window



E15 Switch for heated rear window

Ignition timing sender

G28 Engine speed sender

J220 Motronic control unit

T3! Plug connection, 3-pin, black, for ignition timing

T3m Plug connection, 3-pin, grey, for engine speed sender

T3r

Plug connection, 3-pin, white, in left of boot Plug connection, 10-pin, brown, connector panel in T10b

auxiliary relay carrier Heated rear window

Earthpoint, behind dash panel on left

Earth connection -1-, in dash panel wiring loom

Earth connection, in exterior mirror wiring loom

Earth connection (control unit), in Motronic wiring


(219) Earth connection -2-, in tailgate wiring loom

Switch only on vehicles without air conditioner Switch on vehicles with air conditioner ⇒ Current Flow Diagram No. 89, model year 1993.

Z1




Turn signal and hazard warning flasher system, licence plate light





Bulb monitoring device, trailer coupling



Light switch

J123 Front bulb monitoring device Rear bulb monitoring device J124

J189 Auto Check system

M1 Bulb for left side light M2 Bulb for right tail light

МЗ Bulb for right side light М8 Bulb for rear right turn signal light

M10

T10a

Bulb for right stop light
Plug connection, 10-pin, yellow, connector panel in
auxiliary relay carrier
Plug connection, 10-pin, brown, connector panel in T10b

auxiliary relay carrier

U10 Socket for trailer operation Earth connection -1-, in rear wiring loom


Earth connection -2-, in rear wiring loom

Connection (15a), in dash panel wiring loom

Connection (right turn signal), in rear wiring loom



Trailer coupling, rear fog light



E18 F4 F76 Switch for rear fog light Switch for reversing lights Electronic thermoswitch

Rear fog light cutout relay (trailer operation) Indicator lamp for hazard warning system and right turn J269 K64

signal Indicator lamp for left turn signal

L46 L47 M16 M17 S26

Indicator lamp for left turn signal
Bulb for left rear fog light
Bulb for right rear fog light
Bulb for left reversing light
Bulb for right reversing light
Bulb for right reversing light
Fuse for trailer socket (in auxiliary fuse holder)
Plug connection, 1-pin, black, behind dash panel on left
Plug connection, 3-pin, behind dash panel on left
Plug connection, 5-pin, black in late of boot T1f T3ag

Plug connection, 3-pin, behind dash panel on left Plug connection, 6-pin, black, in left of boot Plug connection, 8-pin, in right of engine compartment Plug connection, 8-pin, in right of engine compartment Plug connection, 10-pin, brown, connector panel in auxiliary relay carrier Plug connection, 26-pin, yellow, on dash panel insert Plug connection, 26-pin, blue, on dash panel insert Socket for trailer operation T6b T8e Z8f T10b

T26

Earthpoint, in left of boot

(81) Earth connection -1-, in dash panel wiring loom


Earth connection -1-, in rear wiring loom

Earth connection -1-, in tailgate wiring loom

Earth connection -2-, in tailgate wiring loom



Electrically adjustable driver and front passenger mirror



T6af Plug connection, 6-pin, in left rear-view mirror T6ag V17 Plug connection, 6-pin, in right rear-view mirror

Motor for adjusting mirror (driver side)

V25 Motor for adjusting mirror (front passenger side)


Heated rear-view mirror (driver side)

Heated rear-view mirror (front passenger side)

(107) Earth connection, in rear-view mirror wiring loom

Connection -1-, in mirror adjustment/heater wiring loom

Connection -2-, in mirror adjustment/heater wiring loom



Technical data

Engine number

The engine number ("engine code letters" and "serial number") is stamped on the front right of the cylinder head.

In addition, a sticker with "engine code letters" and "serial number" is affixed to the toothed belt guard.

The engine code letters are additionally listed on the vehicle data plate.

00-1

Engine features

Code letters		ADU	Code letters	ADU
Manufactured from		01/94 ►		
Displacement	ltr.	2.226	Valve timing	
Engine output	kW at rpm	232/6500	at 1 mm valve lift and 0 mm valve clearance	
Torque	Nm at rpm	400/2400	Inlet opens ATDC	13°
Bore dia.	mm	81	Inlet closes ABDC	35°
Stroke	mm	86.4	Exhaust opens BBDC	24°
Compression	,	9.3	Exhaust closes ATDC	1°
RON/MON 98/88 recomm	nended min. RON	91		4
Injection system		Motronic		
Ignition system		Motronic		
Knock control		yes		
Self-diagnosis		yes		
Lambda control		yes		
Catalytic converter		yes		
Charging		yes		

Motronic self-diagnosis

Fault table

 The differences from engine code ABY are described below; all other faults ⇒ Audi 80 1992 Motronic Fuel Injection and Ignition System (5-Cylinder).

Output on printer of V.A.G 1551	Possible cause of fault	Possible effects	Rectifying fault
00543 Maximum engine speed exceeded * Signal too large	- Engine overrevs as a result of incorrect gear- shift (engine speed greater than 7440 rpm)	- Possible engine damage	Rectify mechanical damage

^{*)} This fault type is displayed in addition to the component.

01-1

Basic setting of the engine with V.A.G 1551

 The differences from engine code ABY are described below; the remaining procedure for the basic setting ⇒ Audi 80 1992 Motronic Fuel Injection and Ignition System (5-Cylinder).

Explanation of readouts in display fields 1 to 10

Display field	Specified readout	Corresponds to measured value	Designation	Remarks	
1	184215	85105°C	Coolant temperature	Requirement for all other readouts/ specifications	
2	1524		Engine load	With air conditioner off, without ancillaries	
3	7684	760840 rpm	Engine speed	With air conditioner off, without ancillaries	
4	121135		Idle speed stabilization operating range	Change in air flow caused by -N71	
5	70125		Idle speed stabilization map zero point	Internal computed value	
6	123137		Idle speed stabilization load adaptation	Change in air flow caused by -N71	
7	4161		Idle speed stabilization map control	Internal computed value	
8	123133		Lambda control	After about 1.5 minutes	
9	100150		Programmed value for lambda control	If readout is high, perform road test again	
10	3537	812° BTDC	Ignition angle when idling	Ignition angle computed by -J220	

Display group number 03

Display field	Readout on V.A.G 1551	Cause of fault	Rectifying fault
1	760840 rpm	⇒ Display group number 01, display field 1	
2	2535 %	o.k.	
	greater than 35 %	Air conditioner on Electrical components on AC compressor running, although air conditioner off Air mass meter –G70 faulty Central hydraulic pump faulty Unmetered air between turbocharger and throttle valve	 Switch off air conditioner Switch off ancillaries Test air conditioner ⇒ Repair Group 87 Test –G70 ⇒ Repair Group 24 Test central hydraulic pump ⇒ Repair Group 48 Rectify cause of fault
	less than 25 %	Unmetered air between air mass meter —G70 and turbocharger or downstream of throttle valve Vacuum hose dropped off Crankcase ventilation leaking Fuel tank ventilation Solenoid valve 1 for activated charcoal filter jamming Air mass meter —G70	- Rectify cause of fault - Check vacuum system - Check crankcase ventilation - Check fuel tank ventilation system - Perform final control diagnosis ⇒ Repair Group 01 - Test –G70 ⇒ Repair Group 24

Display field	Readout on V.A.G 1551	Cause of fault	Rectifying fault
3	510 <°	o.k.	
3	greater than 10 <*	Throttle valve potentiometer –G69 faulty or incorrectly set Throttle cable incorrectly set Throttle valve jamming	Test throttle valve potentiometer G69 ⇒ Repair Group 24 Adjust throttle cable ⇒ Repair Group 20 Test throttle valve
	less than 5 <°	Throttle valve potentiometer –G69 faulty or incorrectly set	 Test throttle valve potentiometer G69 ⇒ Repair Group 24
4	° C	Dependent on ambient temperature; no specification	

Display group number 04

Display field	Readout on V.A.G 1551	Cause of fault	Rectifying fault
1	760 840 rpm	⇒ Display group number 01, display field 1	
2	2535 %	⇒ Display group number 03, display field 2	
3	4 km/h	o.k. (if speed less than 4 km/h, a constant 4 km/h is displayed)	
4	00010	o.k. (only when idling)	
	00000	Idle speed switch -F60 faulty	- Test -F60 ⇒ Repair Group 24

01-5

Coding variants of Motronic control unit –J220

The control unit identification and the coding are displayed when the fault memory is interrogated.

The coding is performed through the wiring loom.

Only coding 4 is permissible.

Coding 4:

- Road speed limited to 270 km/h.
- Contact 38 of Motronic control unit is permanently connected to earth.
- If coding 1 is displayed for the control unit identification, service cable connection between contact 38 and earth.

Important!

If the earth connection is removed, the road speed limit is cancelled. It is not permitted to perform such a modification.

Removing and installing engine

⇒ Workshop Manual Audi 100 1991 ► Engine code AAN 5-Cyl. Injection Engine (4-Valve, Turbo), Mechanics Edition 07.91 Bulletin No. 4 Edition 09.93 as of page 10–1

Modifications

Note, information:

Coolant pipe to expansion tank modified.

10-1

Crankshaft group

⇒ Workshop Manual Audi 100 1991 ► Engine code AAN 5-Cyl. Injection Engine (4-Valve, Turbo), Mechanics Edition 07.91 Bulletin No. 4 Edition 09.93

Modifications

- Page 13-14

Note, information:

- Rolled main bearings on crankshaft
- Crankshaft main bearing shells with 45° groove

Cylinder head, valve gear

⇒ Workshop Manual Audi 100 1991 ► Engine code AAN 5-Cyl. Injection Engine (4-Valve, Turbo), Mechanics

Modifications

- Page 15-1

Note, information:

"Metal" cylinder head gasket; installation as before.

Lubrication system

⇒ Workshop Manual Audi 80 1987 ►, Audi 90 1987 ► Engine code 3B 5-Cyl. Injection Engine (4-Valve, Turbo), Mechanics

Note, information:

- If considerable quantities of metal swarf or abrasion caused by seizure damage such as crankshaft and conrod bearing damage are found in the engine oil when performing repairs to the engine, it is necessary not only to carefully clean the oil passages but also to replace the oil cooler in order to avoid consequential damage.
- The oil level must not exceed the max. marking risk of damage to catalytic converter!

Modifications:

- None

Cooling system


⇒ Workshop Manual Audi 80 1987 ►, Audi 90 1987 ► Engine code 3B 5-Cyl. Injection Engine (4-Valve, Turbo), Mechanics Edition 01.91

Modifications

- Page 19-1

Note, information:

- Modified coolant pipe connection Fig. 19-348/6 from coolant thermostat housing to heat exchanger, additional outlet for coolant expansion tank.
- Moulded part (seal) below coolant thermostat.
- Drive gear for coolant pump, No. of teeth was 29 is now 26.



A20-0016

Fuel supply system

⇒ Workshop Manual Audi 100 1991 ► Engine code AAN 5-Cyl. Injection Engine (4-Valve, Turbo), Mechical Bulletin No. 4 Edition 09.93

Modifications

- Page 20-16

Dismantling and assembling fuel pump


- Bolt feed pipe –1 tight to the fuel pump, as shown in the plan view (top part of Fig.). δ = 50°
 - Attach electrical wiring to the fuel feed pipe, as shown in the Fig.
 - After tightening the cable ties -2-, cut off excess length.

20-1

- Page 20-21

Testing delivery of fuel pump

- Test delivery by switching on switch of remote control V.A.G 1348/3A for 15 seconds (press button and hold).
- Refer to the diagram for the specifications for testing minimum delivery.
 - Minimum delivery measured in cm/15 seconds at the return pipe.
- **Voltage at fuel pump when engine switched off and pump running about 2 volts less than battery voltage.




Charging

⇒ Workshop Manual
Audi 100 1991 ►
Engine code AAN
5-Cyl. Injection Engine (4-Valve, Turbo),
Mechanics Edition 07.91
Technical Bulletin No. 4
Edition 09.93

Modifications

- Page 21-3
- Hexagon nut Fig. 21-100 / 12
- The hexagon nuts –arrows– can only be slackened with a 12 mm ring wrench which has been ground flat at both sides of the ring.
 - Remove coolant pipe to the turbocharger and bracket for oil filter in order to improve access.
 - It may be necessary in certain instances to use an open-end wrench.




21-1

- Page 21-14


Removing and installing parts of charge air cooler

- 1 Charge alr cooler
- 2 Hexagon bolt, 22 Nm
- 3 Pressure pipe
- 4 Hexagon bolt, 22 Nm
- 5 Hexagon nut, 22 Nm
- 6 Shield
- 7 Shield
- 8 Pressure pipe
- 9 Hexagon nut, 22 Nm
- 10 Pressure hose
- 11 Pressure pipe
- 12 Pressure hose
- 13 O-ring seal • Replace



Avant RS2 1994 ► 000.5463.59.20

Edition 03.94



Testing exhaust gas turbocharger and blow-off valve

- Connect turbocharger tester V.A.G 1397/A between the vacuum hose –arrow– and the intake manifold.
 - Fit connector coupling of vacuum hose to connection -I- of the turbocharger tester.
 - Run test hose along the rear edge of the bonnet and through the opening of the right window into the interior of the car.
 - Switch on turbocharger tester. Set range switch to position –I-, fit test hose onto connection fitting –I-.
 - Accelerate car in 4th gear from about 60 km/h and full throttle and keep a check on rev counter.
 - At 3000 rpm, press memory button M on turbocharger tester V.A.G 1397/A.

Charge air temperature in °C	10°	25°	45°	55°
Height above MSL		Boost pressure in	n bar at full load	<u> </u>
0 to 1600 m	2300 up to 2400 mbar			
at 2300 m	2200 up to 2300 mbar			

21-3

Note:

- The hose pipes must be absolutely free of leaks otherwise incorrect measurements may occur.
- Ensure that the test hose is not jammed at the bonnet and side window.
- When the memory button M on the turbocharger tester is pressed, the last reading is stored and retained until the memory button M is again pressed or until the tester is switched off.
- Storage of the reading is indicated by the comma in the display panel flashing.
- If the battery voltage of the turbocharger tester drops below the specified level, an arrow appears in the top left corner of the display. An incorrect readout may be shown.
- Before testing the car, drive at a brisk speed for at least 3 km (without stopping at traffic lights or similar).
- As the boost pressure is measured when driving, a second person is required for operating the turbocharger tester for safety reasons.
- Perform at least three measurements and calculate an average figure.

Motronic components

Technical data

System pressure (gauge pressure in bar) with engine running (idling):				
without vacuum: 3.84.0 with vacuum: 3.23.7				
Holding pressure for 10 minutes (minimum pressure in bar):				
when engine cold: 3.3 when engine hot: 3.6				
Injectors Quantity injected in ml/20 s 130140				
Idle speed test	Engine speed 770830 rpm			
	CO content upstream of CAT 0.50.9 % vol			


24-1


Servicing Motronic injection system

Testing system pressure and holding pressure

Specified pressures for pressure test:

- 3.8...4.0 bar when pump running
- 3.3...3.5 bar immediately after switching off fuel pump
- For procedures as well as connection of pressure measuring device
 ⇒ Audi 80 1992 Motronic Fuel Injection and Ignition System (5-Cylinder).





Testing injectors

- → Resistance of injector:
 - 13.5...15.5 Ω.

- Quantity injected per injector in 20 sec:
 - 130...140 ml,
 - Procedures ⇒ Audi 80 1992 Motronic Fuel Injection and Ignition System (5-Cylinder).

24-3


Testing altitude sender -F96

(Models without trailer coupling or not towing a trailer)

Notes:

- On models with a trailer coupling, the altitude sender signal passes through the trailer recognition control unit –J345 to the Motronic control unit –J220.
- If vehicle is not fitted with trailer coupling, a bridge is provided at the relay position for –J345 which passes the signal of the altitude sender to the Motronic control unit –J220 instead of through the control unit for trailer detection.
- The trailer recognition control unit is located in the auxiliary relay carrier below the dash panel on the left, relay position 16 (⇒ Current Flow Diagram).
- Testing trailer recognition control unit –J345 ⇒
 Reducing engine output when towing a trailer,
 page 24–10.

The altitude sender is located in the front passenger footwell below the trim panel in a recess of pillar A.



Avant RS2 1994 ► 000.5463.59.20

1	Read measured value block			→
	1 2	3		4

- Read measured value block and select display group 02 ⇒ Repair Group 01.
- Readout in display:
 - Check readout in display field 4.

The current atmospheric pressure in mbar is displayed.

Notes:

- The current atmospheric pressure is dependent on the altitude and pressure fluctuations resulting from meteorological conditions.
- The atmospheric pressure at sea level is about 1013 mbar when meteorological conditions are normal and decreases by about 100 mbar for each 1000 m altitude.
- The weather-related pressure fluctuations (ignoring extreme weather conditions and tropical countries) are generally less than ± 50 mbar.
- If a constant 968 mbar is displayed instead of the current atmospheric pressure (fault 00528 in fault memory), or if the figure displayed differs greatly from the figure which would be normal as a result of altitude and weather conditions

 Testing voltage supply of altitude sender and cable connections.

24-5

Notes:


- If the altitude sender fails, the control unit assumes a substitute altitude of about 3000 m and a constant 968 mbar.
- After rectifying the cause, the fault is classified as a sporadic fault and normal control is resumed.

Testing voltage supply of altitude sender

- Unplug connector from altitude sender.
- Switch on ignition.
- Connect hand-held multimeter V.A.G 1526 with auxiliary cables from V.A.G 1594 for voltage measurement in turn between contacts 1 and 3 as well as 2 and 3.

Specification in each case: 4.5...5.5 V


 If one of the specifications is not achieved, test cable connections to the Motronic control unit.




Testing cable connection of altitude sender


- Switch off ignition.
- Connect test box V.A.G 1598 with adapter cable V.A.G 1598/5 only to the wiring soom to the Motronic control unit ⇒ Repair Group 01.
- Remove bridge or unplug control unit for trailer recognition —345 at the auxiliary relay carrier, relay position 16.
- Test the following cables for open circuit or short circuit on the basis of the current flow diagram:
 - From contact 1 at connector for -F96 to contact 2 at relay base for -J345.
 - From contact 5 at relay base for -J345 to socket 9 of the test box.
 - From contact 2 at connector for –F96 to socket 12 of the test box.
 - From contact 3 at connector for –F96 to socket 30 of the test box.

Specification: max. 1.0 Ω .





Rectify any open circuit or short circuit in wiring.



 If vehicle fitted with trailer coupling, test control unit for trailer recognition contact 2 to contact 5 for continuity.

Specification: approx. 0 Ω .

 Re-insert bridge or plug intrailer recognition control unit –J345 at auxiliary relay carrier, relay position 16.

Avant RS2 1994 ► 000.5463.59.20

24-8

Edition 03.94

- Connect adapter cable V.A.G 1598/5 to the Motronic control unit.
- Switch on ignition.
- Connect hand-held multimeter V.A.G 1526 in turn between sockets 12 and 30 as well as 9 and 30.

Specification for socket 12 and 30: 4.5...5.5 V.

Specification for socket 9 and 30: 0.5...5.0 V.

- If one of the specifications is not achieved, replace Motronic control unit.
- After rectifying all the faults, interrogate and erase fault memory.

24-9

Reduction in engine output when towing a trailer

(Models with trailer coupling when towing a trailer)

Notes:

- When towing a trailer, the engine output is reduced to about 169 kW (230 HP). This is done by the trailer recognition control unit ~J345 interrupting the signal of the altitude sender ~F96 and supplying a fixed value of about 0.3 V in its place to the Motronic control unit ~J220.
- The fixed value of 0.3 V corresponds to a pressure level of 600 mbar (about 4200 m above MSL).
- The trailer recognition control unit →J345 is located in the auxiliary relay carrier below the dash panel on the left, relay position 16 (⇒ current flow diagram).
- Either a trailer or a separate light unit (e.g. test facility for trailer socket) must be used for the test.

Test requirements:

- Altitude sender F96 o.k. (no fault in fault memory).
- Trailer lighting operates.
- Unplug trailer connector.
- Read measured value block and select display group 02 ⇒ Repair Group 01.

Readout in display:

→ 4

- Check readout in display field 4.

The current atmospheric pressure is displayed in mbar.

- Plug in trailer lighting.


The fixed value of 600 mbar supplied by -J345 is displayed.

 If no change occurs from the current reading to the fixed value for trailer operation when the trailer lighting is plugged in, or if the constant value of 968 mbar is displayed instead of the current value (and fault 00528 is thus stored), replace trailer recognition control unit.

24-11

.

Read measured value block



Removing and installing exhaust system

Notes:


- Aligning exhaust system free of tension ⇒ page 26–7
- Checking exhaust system for leaks \Rightarrow page 26–11
- Separation point between centre silencer and tail silencer ⇒ page 26–5 Fig. 1
- Always fit new gaskets and hexagon nuts.
- 1 Blow-off valve
- 2 Gasket

3 - Turbocharger


◆ Removing and installing

⇒ Workshop Manual Audi 100 1991 ►
Engine Code AAN
5-Cyl. Injection Engine (4-Valve)
Engine, Edition 07.91
Technical Bulletin No. 4
Edition 09.93 Edition 09.93

26-1



- 4 Corrugated tube
 Fitting location ⇒ page 26–6 Fig. 2
- 5 Hexagon nuts, 25 Nm
- 6 Gasket
- 7 Screw plug, 27 Nm
- 8 Lambda probe, 50 Nm
 - Testing
- ⇒ Repair Group 24
 - Grease thread with G5; grease must not get into the slot area of probe body
- 9 Gasket
- 10 Hexagon nut, 30 Nm
- 11 Hexagon nut, 30 Nm
 Width across flats, 15
- 12 Front exhaust pipe
 Clearance to heat shield of left drive shaft about 16 mm



- 13 Intermediate pipes

 Lock nut, CO sampling 25 Nm

 Aligning ⇒ page 26–10

14 - Hexagon bolt, 25 Nm

- 15 Double clips
 Fitting location ⇒ page 26-10

 - Tighten evenly, 40 Nm
 Replace each time after slackening the screw union

16 - Bracket

Align ⇒ page 26–8

17 - Hexagon bolt, 25 Nm

- 18 Tail sliencer

 Align tail pipes ⇒ page 26–9


 Adjust pretension of exhaust system ⇒ page 26–8

19 - Suspension loop

20 - Centre silencer

Align when performing repairs ⇒ page 26–9

26-3



000.5463.59.20

21 - Seals

22 - Catalytic converter

- Ensure adequate clearance between catalytic converter input pipe and heat shield for transmission bearing ⇒ page 26–7
- 23 Seal

24 - Hexagon bolt, 25 Nm

25 - Catalytic converter suspension

 Location of parts ⇒ page 26-6 Fig. 3

26 - Hexagon nuts
• Welded in place, replace if damaged

27 - Hexagon nut, 60 Nm

28 - Gasket for exhaust manifold

29 - Exhaust manifold

30 - Hexagon nut, 25 Nm

Edition 03.94





Fig. 1 Separation point between centre silencer and tail silencer

- A separation point is provided for replacing the centre silencer or tail silencer, respectively.
- Separate exhaust pipe between centre silencer and tail silencer at the point marked by a groove.
- Size −a− about 300 mm.
 - A short double clip is provided for connecting centre silencer and tail silencer when performing repairs, 40 Nm.
 - Align centre silencer when performing repairs \Rightarrow page 26–9.
 - The double clip should be installed horizontally.
 - The screw union of the double clip must be located on the right side of the exhaust pipe.



Flg. 2 Installation position of corrugated tube

 Flow direction –arrow– from exhaust manifold to exhaust system.




Fig. 3 Suspension of catalytic converter

- Location of parts
 - 1 Hexagon nut, 25 Nm
 - 2 Catalytic converters


26-6

Aligning exhaust system free of tension


The exhaust system should be aligned free of tension as described below in order to avoid noises and stresses in the exhaust system.

Notes:

- Slacken all the bolted joints of the exhaust system including the suspension of the catalytic converter.
- The dimensions stated in the Fig. are a guide.
- The exhaust system is aligned when cold.
- The procedure described below must be performed in the order stated.
- The clearance between front exhaust pipe and heat shield of the left drive shaft must be at least 16 mm.
- Align catalytic converter; it is important to ensure that an adequate clearance of at least 10 mm exists between catalytic converter input pipe and heat shield for transmission bearing (arrow).





26-7



Notes:

- The catalytic converters are shown from the rear, viewed in direction of travel.
- The size -a- must be measured from the centre -b- of the catalytic converter collision guard.
- Tighten flanged joint between front exhaust pipe and catalytic converter on left and right. The screwed joints of the flanges of front exhaust pipe/ catalytic converter must be tightened in such a way that the flanges have the same clearance to each other all round, 25 Nm.
- Tighten suspension of catalytic converter free of tension, 25 Nm.
- Adjust pretension at the left mounting bracket of the tail silencer. Size—a—at least 18 mm should be obtained by moving in the double clip.






Notes:

- After tightening the bracket, the opening –b–must not be blocked.
- Brackets which are permanently misshapen or damaged must be replaced.
- Align tail pipes so that sufficient clearance to the pump exists in all directions.
- Align centre silencer when performing repairs.

Note:

The illustration shows the front hanger at the centre silencer.

- The pretension –a– of 7 mm should be obtained by moving it in the double clip.
 - The clearance -b- between the loop and the securing straps must be at least 2 mm at both hangers.




26-9

 Align intermediate pipes as shown in the Fig. Size -a- about 20°

Note:


The intermediate pipes are shown from behind, viewed in direction of travel.



 Align screw unions of the double clips as shown in the Fig., and tighten, 40 Nm.


Notes

- Double clips are shown from the rear, viewed in direction of travel.
- After slackening the screw union, the double clips must be replaced.
- Tighten bolted connection of flanged joint of catalytic converter/intermediate pipes. The bolted connection of the flanges of the catalytic converter/ intermediate pipes must be tightened in such a way that the flanges have the same clearance to each other all round, 25 Nm.



The exhaust system should be checked for leaks by adopting the following procedure:

- Run engine.
- Seal tail pipes for the duration of the leak test, e.g. with rags or plugs.
- Check the following joints by listening for leaks: Cylinder head / manifold, manifold / front exhaust pipe etc.
- Rectify any leaks found.




Replacing wheel bearing housing

- Wheel bearing housing
 With Ø 82 mm bearing bore
 Do not grease bearing seat in wheel bearing housing before pressing in wheel bearing
 In order to press out the pivot journal of the pressent wide out the
 - nal, on no account widen slot in wheel bearing housing (seat for pivot journal)
 - After installing and removing or re-placing, check front axle alignment

- Plug
 On vehicles fitted with anti-locking a spring sleeve for brake system, a spring sleeve for mounting the speed sensor is inserted instead of the plug
- 3 Hexagon bolt, 10 Nm
- 4 Splash guard

40-1



5 - Wheel bearing

Important!

Pay attention to installation position: Large inner diameter of wheel bearing faces wheel hub.

- Is destroyed when pressing out
 Pressing out ⇒ Fig. 2
 Inserting ⇒ Fig. 3

- 6 Wheel hub

 Pressing out ⇒ Fig. 1

 Inserting ⇒ Fig. 4

 Pressing off bearing inner race ⇒ Figs. 5 and 6

7 - Hexagon bolt, 85 Nm

8 - Adapter for brake caliper

For attaching the four-piston brake caliper

Avant RS2 1994 ▶ 000.5463.59.20

Edition 03.94




Fig. 1 Pressing wheel hub out of wheel bearing housing

Note:

Use a \emptyset 200 x 180 x 4 mm ring which is closed at one end for pressing out the wheel hub.




Fig. 2 Pressing out wheel bearing





Fig. 3 Pressing wheel bearing -A- in until fully home

Large inner diameter of wheel bearing faces wheel hub.



VW521/2

Fig. 4 Pressing wheel hub into wheel bearing

Notes:

- When pressing in, the tool VW 544 must be supported only at the bearing inner race.
- Tool 3144 with angled side facing up.

Avant RS2 1994 ► 000.5463.59.20




Fig. 5 Inserting separating device

Insert separating device into the annular groove of the bearing inner race and pre-tension appro-priately with spindle.

Use commercially available separating device, e.g. KUKKO 15–17.





Fig. 6 Pressing bearing inner race off wheel



40-5

Removing and installing suspension strut and drive shaft

1 - Plastic nut

Screw onto wheelhouse

3 - Self-locking nut, 60 Nm

Always replace
 Tighten with torque wrench ⇒ page 40–11 Fig. 2

4 - Dished stop plate


5 - Suspension strut

Do not unbolt from wheel bearing housing in order to replace shock absorber, coil spring and wheel bearing, but remove complete and install (camber setting)

6 - Gasket

Replace; pull off protective strip and stick into the joint

Edition 03.94



7 - Drive shaft


To remove, unbolt coupling rods at both sides of suspension strut and push anti-roll bar up, unbolt from the flanged shaft and also remove hexagon bolt + washer

Important!

If it is necessary to remove vehicles on which the drive shaft has been removed, an outer joint must be installed first of all in place of the drive shaft otherwise the wheel bearing will be damaged.

- Pay attention to different lengths on left and right
 When removing the drive shaft, pull back ABS speed sensor slightly first of all; press in until fully home when installing

40-7



Avant RS2 1994 ► 000.5463.59.20

Edition 03.94

8 - Backing plate

9 - Cylindrical bolt, 80 Nm

10 - Hexagon bolt • Always replace

11 - Track rod

 Prize off steering arm with two-legged puller ⇒ page 40-11 Fig. 1

12 - Wheel bearing housing with wheel hub


- To press off the pivot journal, on no account widen slot in wheel bearing housing (seat for pivot journal)

 After installing, check front axle
- alignment

13 - Hexagon bolt

- Always replace
 Bolt head faces in direction of travel

40--8



- Axle link with axle joint
 When removing from wheel bearing housing, do not widen slot in wheel bearing housing
 Joint journal diameter 19.0 mm
 Only as forged version


15 - Self-locking nut, 30 Nm • Always replace

16 - Self-locking nut

- Always replace
 Tighten to 110 Nm and then tighten a further 90*
- 17 Washer

18 - Self-locking nut, 50 Nm • Always replace

- 19 Spacer



40-9

- 20 Hexagon collar bolt

 Always replace

 Tighten M16 x 1.5 bolt to 200 Nm and then tighten a further 90*

 Slacken and tighten only when vehicle standing on its wheels (risk of initial) injury)

21 - Self-locking nut, 40 Nm • Always replace

- 22 Coupling rod






Fig. 1 Pressing off track rod joint



➡ Fig. 2 Tightening nut with torque wrench

Counter-hold coupling rod with hexagon socket wrench.



Replacing wheel bearing housing

Note:


Before removing the wheel bearing housing, remove rear wheel parking brake ⇒ Servicing rear wheel parking brake, page 46–9.

- Wheel bearing housing
 Do not grease bearing seat in wheel bearing housing before pressing in wheel bearing
 After replacing the wheel bearing housing, check rear axle alignment
 Is supplied as replacement part with hole for mounting the clamping sleeve or the speed sensor

- Clamping sleeve
 Grease all round with brake cylinder paste before inserting into wheel
 - bearing housing

 Press into wheel bearing housing until fully home

42-1



Speed sensor

- Pull out to remove
- To install, press in by hand until fully

4 - Bonded rubber bush
• Removing and installing ⇒ Workshop Manual

5 - Self-locking nut, 46 Nm

Always replace


Brake mounting plate
 Mounting plate of parking brake and of brake caliper

7 - Hexagon bolt

- 8 Hexagon bolt, 46 Nm
- 9 Hexagon bolt, 10 Nm

42-2

Edition 03.94



10 - Wheel bearing

- Wheel bearing
 Inner diameter as stepped design
 Pay attention to installation position: large inner diameter of wheel bearing faces wheel hub
 Is destroyed when pressing out
 Pressing out ⇒ Fig. 2
 Inserting ⇒ Fig. 4

- 11 Wheel hub

 Pressing out ⇒ Fig. 1
 Inserting ⇒ Fig. 3
 Pressing off bearing inner race ⇒ Fig. 5 and Fig. 6

42-3





Fig. 1 Pressing out wheel hub

Note:

Use a Ø 200 x 180 x 4 mm ring \neg A \rightarrow which is closed at one end for pressing out the wheel hub.







Fig. 3 Pressing in wheel hub

Note:

When pressing in, the tool VW 554 must be supported only at the bearing inner race.



- Fig. 4 Pressing in wheel bearing -A- until fully home
 - Large inner diameter of wheel bearing faces wheel hub.




Fig. 5 Inserting separating device


Important!

When pressing off bearing inner race, ensure that the spacer shim -A- is not also pressed off.

 Insert separating device into the annular groove of the bearing inner race and pre-tension appropriately with spindle.

Note:


Use commercially available separating device, e.g. KUKKO 15–17.



→ Fig. 6 Pressing bearing inner race off wheel hub

Avant RS2 1994 ► 000.5463.59.20

42-6



Removing and installing drive shaft

1 - Differential

Gasket
 Pull off protective sheet and stick into the joint

3 - Drive shaft • Service ⇒ Workshop Manual


Important!

Should It be necessary to move the vehicle on which the drive shaft has been removed, an outer joint should be installed first of all in place of the drive shaft otherwise the wheel bearing will be damaged.

4 - Backing plate

5 - Cylindrical bolt, 80 Nm

42-7



Avant RS2 1994 ► 000.5463.59.20

Edition 03.94

6 - Subframe

7 - Spacer


8 - Hexagon bolt + washer

• Always renew

• Tighten M16 bolt to 200 Nm and then tighten a further 90'

• Slacken and tighten only when vehicle standing on its wheels (risk of injury). injury)

42-8




Fitting on tyres

The tyre fitting and removal instructions relate to 17" cup design wheels with asymmetric hump.

Avoid damaging the paintwork of the wheel.

Use a Matra presser V-180 for removing and fitting on the tyres.




- In addition, the assembly lever should be flat-tened at its face end and then rounded (arrow).
 - Fit on the first tyre bead in the usual manner.


Note:

The asymmetrical hump alters its shape over the circumference of the tyre.


For this reason, pay strict attention to the following points when fitting on and removing the tyres.




- Clamp on wheel and coat inside of wheel as well as both tyre beads with assembly paste.
- Replace the valve each time before fitting on the
- Adjust assembly tool to the correct distance.
- a ⇒ 4 5 mm b ⇒ 8 10 mm



- When starting to fit on the second bead, the assembly arm should be positioned opposite the valve. Then, fit the second tyre bead onto the wheel as flat as possible, guide over the assembly head and hold down offset about 90 – 120' using special tool 9539.
- When turning the wheel and fitting on the second bead, the bead of the tyre must be held in the deep bed of the wheel with a second assembly lever and the special tool Matra V-180.




- To make it easier to fit on the tyre, the additional assembly lever should be positioned below the
- When inflating the tyre, the beads must jump across the hump no later than at pressure of 4.5 bar.
- When inflating the tyre, therefore, the bead which is still in the deep bed must be positioned opposite the valve (flatter hump profile); it may be neces-sary to turn the tyre accordingly and re-coat with accombly posts. assembly paste.




Removing tyres

- Set assembly tool to the correct distance.
- a ⇒ 4 5 mm b ⇒ 8 10 mm
 - Begin pressing off the tyre at the valve as the force required here is slightly less. Then press off the tyre on both sides, coating the rim flange with assembly paste when doing this.



- Lift the first side of the tyre over the assembly
 - Place a rag or a chamois leather between wheel and assembly lever as an aid when performing this step.



- In addition, ensure that the tyre is held in the deep bed opposite the removal head.
 - Use the special tool Matra V-180 for this purpose.
 - Remove the second side of the tyre in the usual

44-4

Wheels and tyres


Engine output / kW	Tyre size	Wheel size	Wheel offset and hole circle Ø mm
232	245 / 40 ZR 17	7 J x 17	55 / 130

- Spare wheel with regular tyre
- Only Dunlop SP Sport 8000 tyres may be fitted as summer tyres.

Winter tyres

Engine output / kW	Tyre size	Wheel size	Wheel offset and hole circle Ø mm
232	205 / 55 R 16 89 T / H	6 J x 16	51.3 / 130

• It is a regulation (in Germany) that a visible sticker is affixed in the driver's field of view on vehicles which have a top speed in excess of the maximum permissible speed for winter tyres. This sticker is available from the tyre trade.



Removing and installing ABS components on front axle


1 - Drive shaft with rotor

- Or outer CV joint, is supplied as replacement part with rotor
 Before removing, pull back speed sensor slightly
 After installing, press in speed sensor by hand until fully home

2 - Speed sensor

- Identical part on left and right
 Pull out of wheel bearing housing in order to remove
- To install, press in by hand until fully home
- Plug plug connection for speed sensor, front left ⇒ Fig. 1, front right ⇒ Fig. 2
- Routing of wiring for speed sensor
 ⇒ Fig. 3 and Fig. 4

45-1



Avant RS2 1994 ► 000.5463.59.20

- 3 Clamping sleeve
 Grease all round with brake cylinder paste before inserting into wheel bearing housing
 • Press into wheel bearing housing
 - until fully home

Wheel bearing housing
 Is supplied as replacement part with hole for mounting the clamping sleeve or the speed sensor

5 - Spacer

6 - Hexagon collar bolt

- Always renew
 Tighten M16 x 1.5 bolt to 200 Nm and then tighten a further 90°
 Slacken and tighten only when vehicle standing on its wheels (risk of latins). injury)

Edition 03.94




Fig. 1 Plug connection of front left speed sensor

- Unbolt coolant expansion tank and place to the side.
- Release plug connection from holder and then separate.




Fig. 2 Plug connection of front right speed sensor

 Release plug connection from holder and then separate.







Fig. 3 Routing of wiring for speed sensor at suspension strut

- Insert cable with the grommet into the angle bracket at the suspension strut.
- Insert cable into the clip.




▼ Fig. 4 Routing of wiring for speed sensor at wheelhouse

- Insert cable with grommet into angle bracket.
- Insert cable into the clips along the brake pipe.

Avant RS2 1994 ► 000.5463.59.20

45--4




Removing and installing ABS components at rear axle

- Drive shaft with rotor
 Or outer CV joint, is supplied with rotor as replacement part
 Pull back speed sensor slightly be
 - fore removing
 - After installing, press in speed sensor by hand until fully home

2 - Speed sensor

- Identical part on left and right
 Pull out in order to remove
 To install, press in by hand until fully home
- Routing of wiring ⇒ Fig. 1 and 2

45-5



Avant RS2 1994 ► 000.5463.59.20

Edition 03.94

- Clamping sleeve
 Grease all round with brake cylinder paste before inserting into wheel bearing housing
 Press into wheel bearing housing until fully home

- 4 Wheel bearing housing
 Is supplied as replacement part with hole for mounting the clamping
 - Sleeve or the speed sensor
 Grease hole all round with brake cylinder paste before inserting the clamping sleeve –3–

5 - Spacer

6 - Hexagon collar bolt

- Always renew
 Tighten M 16 x 1.5 bolt to 200 Nm and then tighten a further 90°
- Slacken or tighten only when vehicle standing on its wheels





Fig. 1 Routing of wiring for speed sensor


 Insert cable with rubber grommet into the holder provided at the subframe as well as at the floor assembly.



- Bolt cable tight with retaining plate to subframe.

Note:

The two plug connections for the rear speed sensors are located below the rear seat.



Servicing front brakes

Brembo four-piston brake calipers


Important!

- Install all the parts of the repair kit.
- The brakes can be tested on all com-mercially available brake testers provided the driving speed of the two driving rollers of the tester is not greater than 5.5 km/h.

1 - Brake disc

- Always replace left and right discs
 To remove, unbolt brake caliper first of all
- Turn disc to size evenly, on both sides, starting from the thickness when new
 Diameter of brake disc 304 mm
- Wear limit 30 mm

46-1



- 2 Brake pads

 Always replace on both sides ⇒ page 46-3

 Thickness of brake pads when new
 - 17.5 mm
 - Checking brake pad thickness ⇒ page 46–3
 If pad thickness including backing
 - plate is 8 mm, the brake pads have reached their wear limit and should be replaced

Brake callper housing
 Do not unbolt brake hose and brake caliper for changing brake pads

4 - Washers

5 - Cylinder bolts, 85 Nm

Note:

Each time when replacing or removing the brake pads, the damper plates must also be replaced.

Avant RS2 1994 ▶ 000.5463.59.20


Edition 03.94

Checking thickness of brake pads

- Take off the rear wheels to check the rear brake pads.
- The front brake pads can be inspected with the wheels fitted.
- Check the brake pads visually for signs of wear.
- If the pad thickness (including backing plate) is 8 mm, the brake pads have reached their wear limit and should be replaced.

Replacing brake pads

- Take off wheels.
- Mark brake pads which have to be re-used when removing. It is not permitted to switch the pads from the outside to the inside or vice versa or also from the right to the left wheel as this may result in the car being pulled to one side when braked.



 Compress expanding spring in the middle and release from its mount.


Note:

At the same time or before starting to compress the spring, press the spring toward the brake disc in the area of the retaining plate (release tension). This prevents damage to the retaining plate.


Important!

Before turning back the pistons, extract part of the brake fluid from the brake fluid reservoir. If this is not done, brake fluid may flow out and cause damage—especially if it has been topped up in the meantime. Extract the brake fluid only with a bleeder bottle or a plastic bottle which is used for brake fluid. Brake fluid is polsonous and must on no account be extracted by sucking out through a hose.


 Pull out the brake pads with the brake pad impact extractor. Pay attention to the following points in the case of brake pads with damping plates or vibration dampers with an adhesive layer:



- Pull out brake pads together with the damping plates or vibration dampers. Should this not be possible (depending on state of wear of brake pads), detach the damping plates/vibration dampers from the brake mounting plate with a spatula before removing the pads. In both cases, turn back the brake pads as far as possible with the piston resetting device.
- The spatula must be positioned exactly between brake pad and damping plate/vibration damper in order to avoid damage to the brake piston seals.





 As the damping plates -1- are provided with an adhesive coating, the damping plates must be replaced each time the brake pads are removed or renewed.



Installing

- Turn back pistons into starting position with resetting device, if necessary.
- Clean seat and guide surface of the brake pads in the brake caliper with methylated spirits, a cylinder or special brush to ensure that the brake-pads operate freely in the channel. It is essential to ensure that the brake piston seals (dust caps) are not damaged when performing this operation.
 - Check that the brake calipers are correctly installed. The small pistons must face the brake disc leading side. This can also be recognized by the arrow above the Porsche logo which indicates the direction of rotation of the brake disc.






- Insert new damping plates -1- or vibration dampers into the pistons. As the damping plates or vibration dampers are provided with an adhesive and protective sheeting, the protective sheeting must be pulled off before installing.
 - Insert brake pads. Check that the brake pads are of the correct grade.

Notes:

- The brake mounting plates (rear of brake pads) must not be greased.
- Coat the seat and guide surfaces with a thin film of grease, however, to prevent the brake pads sticking in the brake caliper as a result of corrosion.
- Use Optimoly HT (Cu paste) or Plastilube (Schilling, 73407 Aalen) for this operation.
- Ensure that the expanding spring engages properly (arrow). Do not use force to engage spring (risk of damage to mounting plate).
 - Install new expanding spring if necessary; ensure that the flat side is facing the brake disc.



Servicing rear brakes

Important!

The brakes can be tested on all commercially available brake testers pro-vided the driving speed of the two driving rollers of the tester is not greater than 5.5 km/h.

- 1 -- Brake disc
 Peplace on both sides⇒ Replacing front brake pads, page 46-1
 To remove, unbolt brake caliper first of all and also turn back brake shoes for handbrake
 - Turn disc to size evenly, on both sides, starting from the thickness
 - when new
 Ensure that an adequate wear limit remains


46-9

- Diameter of brake discs 299 mm
 Thickness of brake discs 24 mm
 Wear limit 22 mm
- Adjusting handbrake ⇒ page 46–19

2 - Brake pads


- Replace on both sides ⇒ Replacing front brake pads, page 46–3
 Thickness of brake pads when new

- 17.5 mm
 Wear limit of brake pads 8 mm
 Checking thickness of brake pads ⇒ page 46–3



Avant RS2 1994 ► 000.5463.59.20

Edition 03.94




If the pad thickness including back-ing plate is 8 mm, the brake pads have reached their wear limit and should be replaced

Note:

Replace the damping plates each time the brake pads are renewed or removed.

- Brake caliper housing
 Do not unbolf brake hose and brake caliper
- 4 Hexagon bolt, 85 Nm




Removing: - Raise vel

- Raise vehicle and take off wheels.
- Release handbrake.


Servicing handbrake

 Unbolt brake caliper (arrow) and attach at a suitable point (do not detach brake hose or brake pipe).




- Remove counter-sunk screws (arrow).
- Insert a screwdriver through the hole of the brake disc and alter the position of the adjusting device until the brake disc can be taken off.
 - Take off brake disc.

46-13




- Remove compression spring -1- (second not visible), adjusting device -2- and bottom return spring.
 - Take out handbrake shoes.




Installing:


- Apply a light coating of grease to adjusting device, pin or expanding lever and contact surfaces of handbrake shoes.
- Fit together expanding lever.




Install top long return spring onto handbrake shoes, fit on handbrake shoes and insert into the expanding lever.




Install compression springs with screwdriver.



- Pull apart handbrake shoes -1- and insert assembled adjusting device -2-.
 - Attach bottom return spring.
 - Centre handbrake shoes.
 - Install brake disc.
 - Insert counter-sunk screws.
 - Install brake caliper.
- Adjust handbrake ⇒ page 46–19.



2 46-928




Removing:

Note:

To remove the handbrake cables, first of all remove handbrake shoes ⇒ page 46–13 Servicing handbrake.

- → Remove expanding lever –1–.
- Push handbrake cable to the rear and pull out of the guide sleeve -2-.
 - Unbolt rear shield for the exhaust system.
- Detach handbrake cables from the compensating bracket -2-
- Pull out securing clips ~1~.
 - Detach mounting plate for handbrake cable at the floor assembly.
 - Take out handbrake cable to the rear through plate at bottom axle link.

46-17



 The retaining strap –arrow– must be fitted as shown in the figure.

Note:

If performing partial replacement of bottom axle link, make hole for mounting the strap of the handbrake cable ⇒ Fig. 46-929 (pay attention to corrosion protection).

Installing:

 Installation of the handbrake cables is performed in the reverse order.

Important!


After installing the handbrake cables, adjust handbrake ⇒ page 46–19.


Adjusting handbrake

Moto


The handbrake must be adjusted if the handbrake lever can be pulled up more than 2 detents with moderate force without the brakes being applied.


- Raise vehicle and take off rear wheels.
- Release handbrake and press back disc brake pads of rear axle until the brake disc rotates freely.
- Remove rear shield for the exhaust system (figure is shown with drive shaft removed to simplify the illustration).
- Slacken adjusting nut of handbrake cable –a–far enough, if necessary, until the handbrake cables are slackened.





- Insert a screwdriver through the hole of the brake disc and turn the adjusting device until the wheel can no longer be turned. Then, turn back adjusting device again until the wheel rotates freely, then turn back a further 2 detents (slacken).
 - Apply handbrake lever 2 detents and turn adjusting nut sufficiently until both wheels can no longer be rotated easily by hand (when handbrake lever applied 4 detents, wheels must be locked).
 - Slacken handbrake lever sufficiently and check whether both wheels now rotate freely.





Servicing four-piston fixed caliper brake system

important!

The brake caliper halves must not be separated.

- On no account open or tighten the bolts marked with an arrow.
 - The piston ring seals, dust caps and damping plates can be replaced with the fixed callper assembled.
 - 1 Dust cap
 - 2 Damping plate
 - 3 Rubber seal (rectangular ring)
 - 4 Piston
 - 5 Brake caliper housing

Note:

Proceed as described in the Workshop Manual for servicing.